











980005















980184



804



1-2-3-4... ○ ○


















980184



09.06.15 / 31.07.17




07 17











1/10






1.










4




5





6





7






8





9




10




11




12



13



14




16

Z L0


3 x 13 mm G21

121 113


The diagram illustrates the installation of a Z L0 shelf bracket. The bracket is shown being attached to a shelf with a 3 x 13 mm G21 screw. A callout box shows a screwdriver and a cross symbol, indicating the screw is to be tightened. The distance from the bracket to the edge of the shelf is marked as 'x'.






352 302





KP 8

A line drawing of a rectangular frame, possibly a window or a door. Two arrows point from the top corners of the frame towards the text 'KP 8' located above the frame. The frame has a central horizontal bar and two vertical bars on the sides.



19






SBV



20



Q35




Modell/Model/Modèle

--	--	--	--	--	--

--	--	--	--	--	--



--	--	--	--	--	--



{121 370}	{ G 1 }	{4x}

Änderungen die dem technischen Fortschritt geschuldet sind behalten wir uns vor !
Bei nicht vorschriftsmäßiger und/ oder nicht fachmännischer Montage wird bei Personen-
und/ oder Sachschäden keinerlei Haftung übernommen.

made by

WIMEX Wohnbedarf// Import Export Handels GmbH/ Postfach 1407/ 49112 Georgsmarienhütte/ Germany