



D Montageanleitung	GB Assembly Instructions	NL Handleiding voor de montage	PL Instrukcja montażu	HU Szerelési útmutató	RO Instrucțiuni de montaj
FR Notice de montage	IT Istruzioni di montaggio	CZ Montážní návod	SK Návod na montáž	TR Montaj talimatı	RU Инструкция по монтажу









Service • Assistenza • Dienstverlening • Servis
Servis • Szerviz • Сервисная служба

AS - 1000 • 8000 • 9000 8000 • 1000 • 8000 • 1000 8000 • 1000 • 8000 • 1000 At. No. • If. Hanyig. E. Sz. Typ. Type. T. T. Type. Type Part	ruhe 4.9055
--	----------------

Nr.	Bezeichnung	Anzahl
1.	AS 420x410x15mm	2
2.	B0 840x412x15mm	1
31.	BLE 808x420x15mm	2
5.	KL 850x420x15mm	1





A5		2x	l		16x
b3		2x	l1		8x
g3		1x	t1		4x
			s3		4x
		x			4x




A5		2x
b3		2x
s3		4x
x		4x


1




l		8x
l1		8x

3





2

l		8x
---	--	----



4

g3		1x
t1		4x

