





ASSEMBLY INSTRUCTIONS - AUFBAUANLEITUNG
- INSTRUKCJA MONTAZU - MONTÁŽNÍ NÁVOD




A  10x40 12	B  7x70 20	C  M6x80 5	D  M6x45 8	E  M6x40 14	F  M6x30 8
G  7	H  Ø 14 8	CH  1	I  1	J  4x	K  8x40 4



45 min.




BENCH SECTIONS
BAUTEILE
CZESY
DÍLY




2443 ① 2443-006 ② 2443-007 ③ 2443-9210 ④ 2443-9211 ⑤ 2443-9201 ⑥ 2443-9200 ⑦ 2443-016

2446 ① 2446-006 ② 2446-007 ③ 2446-9210 ④ 2446-9211 ⑤ 2446-9201 ⑥ 2446-9200 ⑦ 2446-016


1 2x




2 2x



3




4




5

2x




6


2x




1x




1x




7 L




7 R




8 L




8 R




9 L




9 R



10L



10R



ASSEMBLY INSTRUCTIONS - AUFBAUANLEITUNG
- INSTRUKCJA MONTAZU - MONTÁŽNÍ NÁVOD

1359

130(170) x 90 cm


1540



120(160) x 80 cm

1397

110(150) x 70 cm



A  10x40 12	B  7x70 10	C  6,3x30 8	D  4	E  Ø14 2	F  1
G  1	H  4x16 4	I  8x30 2	J  2		



40 min.




BENCH SECTIONS
BAUTEILE
CZESY
DÍLY


1359 - ① 1359-7003 ② 1359-011 ⑤ 1359-007

1540 - ① 1540-7001 ② 1540-008 ⑤ 1540-007


1397 - ① 1397-7000 ② 1397-011 ⑤ 1397-007




1 2x




2 2x




3 2x




4



5



6



7

