





Begur



- | | |
|-----------------------------|----------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (NL) Handleiding voor de montage |
| (CZ) Montážní návod | (IT) Istruzioni di montaggio |
| (RO) Instrucțiuni de montaj | (RU) инструкция по сборке |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (TR) Montaj talimati |



Service • Assistenza • Dienstverlening • Servis

Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название



Begur DB



Nr. • No. • N° • Номер • Č • Sz

SH54

Typ • Type • Tip • Típus • Tipo
Тип

OHNE



A	B	C	D	E	F	G	H
							
2x 6x45	2x 8x20	2x M6	2x M6	4x	8x 8x100	8x 8x40	8x M8
1				2			
							
1x				2x M6x30			

Service • Assistenza • Dienstverlening • Servis

Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название



Begur DB

Nr. • No. • N° • Номер • Č • Sz

SH54


Typ • Type • Tip • Típus • Tipo
Тип


LARO




A	B	C	D	E	F	G	H
2x 6x45	2x 8x20	2x M6	2x M6	4x	8x 8x100	8x 8x40	8x M8
		1		2			
		1x		2x M6x30			




A	B	C	D	E
				
2x 6x45	2x 8x20	2x M6	2x M6	4x






F	G	H	Achtung! Schrauben nicht überdrehen				
			FR Attention! Ne serrez pas trop				
4x 8x100			CZ Dávej Pozor! Nepřetahujte	GB Watch Out! Do not over tighten	IT Attento! Non stringere	RU Осторожно! Не затягивайте	
			RO Ai Grija! Nu strângeți	NL Let Op! Niet te vast		SK Dávaj Pozor! Nepreťahujte	
			PL Uważaj! Nie dokręcać zbyt mocno				TR Dikkat! Üzerinde sıkmayın
			HU Vigyázz! Ne húzza túl				





1		1 x
2		2 x M6x30

