





- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓓ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | Ⓡⓞ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |




Ausgabe: 20221010




Service • Assistenza • Dienstverlening • Serwis
 Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	
Nr. • No. • N° • Номер • С • Sz	6418 8653
Typ • Type • Tip • Típus • Tipo Тип	YS-NT7028








A	M6X12MM  X32	B	 X1	C	 X8
----------	--	----------	--	----------	--

0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200







1

<p>A M6X12MM  X16</p>	<p>B  X1</p>	<p>C  X4</p>
--	---	---



2

A M6X12MM  X16	B  X1	C  X8
---	--	--



3

