



D Montageanleitung
 GB Assembly Instructions
 E Instrucciones de montaje
 F Instructions de montage
 I Istruzioni per il montaggio
 NL Montage-instructie

P Instruções de montagem
 DK Montagevejledning
 S Monteringsanvisning
 PL Instrukcja montażu
 GR Οδηγία μοντάζ
 CZ Návod k montáži

SL Navodilo za montažo
 SK Návod na montáž
 H Szerelési útmutató
 RU Инструкция по монтажу
 TR Montaj kılavuzu



Ax16

Bx1

Cx36

Dx3

Ex2

Fx1

Gx2




(D) Montageanleitung
 (GB) Assembly Instructions
 (E) Instrucciones de montaje
 (F) Instructions de montage
 (I) Istruzioni per il montaggio
 (NL) Montage-instructie

(P) Instruções de montagem
 (DK) Montagevejledning
 (S) Monteringsanvisning
 (PL) Instrukcja montażu
 (GR) Οδηγία μοντάζ
 (CZ) Návod k montáži


(SLO) Navodilo za montažo
 (SK) Návod na montáž
 (H) Szerelési útmutató
 (RUS) Инструкция по монтажу
 (TR) Montaj kılavuzu




1




2




3




4



5



6



D Montageanleitung
 GB Assembly Instructions
 E Instrucciones de montaje
 F Instructions de montage
 I Istruzioni per il montaggio
 NL Montage-instructie

P Instruções de montagem
 DK Montagevejledning
 S Monteringsanvisning
 PL Instrukcja montażu
 GR Οδηγία μοντάζ
 CZ Návod k montáži

SLO Navodilo za montažo
 SK Návod na montáž
 H Szerelési útmutató
 RU Инструкция по монтажу
 TR Montaj kılavuzu



7

