

Ⓛ Aufbauanleitung

Ⓛ Notice de montage

Ⓛ Handleiding voor de montage

Ⓛ Montážní návod

Ⓛ Szerelési útmutató

Ⓛ Montaj talimatları

Ⓛ Assembly instruction

Ⓛ Istruzione di montaggio







Ⓛ Instrukcja montażu

Ⓛ Navod na montaž

Ⓛ Instrucțiuni de montaj

Ⓛ Инструкция по монтажу

# 36-1006-82-000



0  
10  
20  
30  
40  
50  
60  
70  
80  
90  
100  
110  
120  
130  
140  
150  
160

Service  
Serwis




Dienstverlening  
Servis

Dienst kaart  
Сервисная служба



Name • Naam • Naam • Isim • Название

Nr. • No. • Номер


Typ • Type • Тип • Тип




<b>A</b>	006110-82	x2
<b>B</b>	006210-32	x2
<b>C</b>	149312-32	x2
<b>D</b>	149410-32	x2
<b>E</b>	006510-52	x4
<b>F</b>	149311-32	x2



6





13



14


1-000001=



17




18




19

		mm	
6	1-000013-00	8x40	x12
13	1-000117-07	D=28	x8
14	1-000091-07	3x16	x16
17	1-000046-07	L34	x8
18	1-000048-07	15x12	x8
19	1-000057-57	3,5x40	x8


1.



2.



3.



4.

