



RO

HU

PL INSTRUKCJA MONTAŻU INSTRUKCJA OBSŁUGI GB ASSEMBLY INSTRUCTIONS INSTRUCTION MANUAL

MONTAGEANLEITUNG
BEDIENUNGSANLEITUNG

NL

HANDLEIDING VOOR DE MONTAGE
GEBRUIKSAANWIJZING

TR MONTAJ TALIMATI RU HCTPYKLUR ПО МОНТАЖУ ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ


INSTRUCȚIUNI DE INSTALARE INSTRUCȚIUNI DE UTILIZARE INSTRUCȚIUNI DE UTILIZARE INSTRUCȚIUNI DE INSTALARE MANUALE DI ISTRUZIONI


FR NOTICE DE MONTAGE MONTÁŽNY NÁVOD NÁVOD NA POUŽITIE

SZERELÈSI ÙTMUTATÁS
KEZELÉSI UTASÍTÁS

CZ


MONTÁŽNÍ NÁVOD
NÁVOD K POUŽITÍ
















(2)














Service — Assistenza — Dienstverlening — Serwis— **Сервисная служба** Servis — Szerviz —

	B	
M8×110	 M 8	Ø8×24
Ø8	 Ø 4 × 40	Ø 50x25