

D Montageanleitung

GB Assembly instructions

NL Handleiding voor de montage

PL Instrukcja montażu

HU Szerelési útmutató

RO Instrucțiuni de montaj

FR Notice de montage


IT Istruzioni di montaggio

CZ Montážní návod

SK Návod na montáž

TR Montaj talimatı

RU Инструкция по монтажу



e11		16x
n		64x
y4		1x










Service • Assistenza • Dienstverlening • Servis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Имя Nazwa • Imięno • Název • Мѣ Депицкѣ • Ём • Названне	Lady II
Nr. • No. • N° • Номер • C • Sz	
Typ • Type • Тр • Трпс • Трп	4.7421

1.	AS	786x370x15mm	2
2.	BL	824x370x15mm	2
3.	MS	786x354x15mm	2
4.	RB	254x353x15mm	12
5.	RW	1073x798x3mm	1



e11		16x
f1		16x
l3		16x
n		64x
y4		3x
z		15x
s3		4x
x		4x

