












(D) Montageanleitung
»Joker 4«

(FR) Notice de montage
»Joker 4«

(NL) Handleiding voor de montage
»Joker 4«

(CZ) Montážní návod
»Joker 4«

(HU) Szerelési útmutató
»Joker 4«

(TR) Montaj talimati
»Joker 4«

(GB) Assembly instructions
»Joker 4«




(IT) Istruzioni di montaggio
»Joker 4«

(PL) Instrukcja montażu
»Joker 4«

(SK) Návod na montáž
»Joker 4«

(RO) Instrucțiuni de montaj
»Joker 4«

(RU) Инструкция по монтажу
»Joker 4«



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200

Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno •
Názov • Név • Denumire • İsim • Название

Joker 4

Nr. • No. • N° • Номер • Č. • Sz

7028


Typ • Type • Tip • Típus • Тип • Тип

Kommode



14 Anthrazit
98 Wotan Eiche
11.25 Beton / Weiss
11 WeissGL / Weiss











D

Leim

GB

Glue

FR

Colle

IT

Colla

NL

Lijm

PL

Klej

CZ

Lepidlo

SK

Glej

HU

Enyv

RO

Adeziv















TR



Tutkal






RU

Клей





 10 x a	 10 x b	 24 x c	 15 x d	 6 x e	 2 x f
 2 x g	 6 x h	 8 x i	 6 x j	 6 x k	 6 x l
 10 x m	 5 x n	 2 x o	 2 x p	 6 x q	 6 x r
 6 x s	 1 x t				








2




10




8




9




3




4



5



6



7

