





Art. Nr. 1859 6105; 3973 5167


LKZ 40947






- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handleiding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |




№	Size/MaB (mm)	Qty	✓	№	Size/MaB (mm)	Qty	✓
1	740x500x24	1		12	912x106x15	1	
2	186x40x15	2		13	106x185x18	2	
3	213x200x18	1		14	912x200x18	1	
4	213x200x18	1		15	1001x500x104	1	
5	186x40x15	4		16	742x70x70	4	
6	186x200x18	2		17	165x90x14	3	
7	460x200x18	1		18	165x90x14	3	
8	460x200x18	1		19	258x80x14	3	
9	442x200x18	1		20	286x100x18	3	
10	442x200x18	1		21	267x157x3	3	
11	912x200x18	1		22	71x38x38	2	



A 030093  x34	B 030110  x34	C 230010 8x32  x56	D 050003 M10x8  x4	E 050017 10x30  x4	F 050021 18x10  x2						
G 030010 5x38  x4	H 030033 7x50  x6	I  x16	J 110021 SW 4  x1	K 250012 3.5x15  x8	L 250024 3.5x35  x6						
M 210029  x3	N 250003 3x12  x6	O 140007  x2	P 070017 30x30  x10	V 070044 10x3  x6	<table><tr><td>Art. Nr.</td><td>H</td></tr><tr><td>39735167</td><td>070038</td></tr><tr><td>18596105</td><td>070039</td></tr></table>	Art. Nr.	H	39735167	070038	18596105	070039
Art. Nr.	H										
39735167	070038										
18596105	070039										
Q 180080  x1	R 090004  x1	S 250012 3.5x15  x1	T 250044 4x40  x1	U 180017  x2	V 070045  x1						




3




B 030110
x4


P 070017
30x30
x6




4



B 030110
x24




5




G 030010
5x38
x4


6



7



7



8

